

Leclerc Looms

Since 1876



1573 Savoie
C. P. 4
Plessisville, Qc.
G6L 2Y6

INSTRUCTIONS TO INSTALL OUR NEW PAWL ON THE VOYAGEUR OR DOROTHY LOOM

Using an $1\frac{1}{64}$ " bit, drill a hole at the center of the post $\frac{1}{2}$ " from the bottom of the breastbeam. Affix the pawl using the $\frac{3}{4}$ " screw #12 supplied.

