

COLONIAL I



COLONIAL I

Contre-balancé



COLONIAL I Jack 4, 8 or 12s Jack, 4s C.-B. 45" or 60"

WOOD	
1119-CL I	Right upright post (w/o batten sword)
1129-CL I	Left upright past (w/o batten sword)
1539-CL I	Right batten support
1529-CL I	Left batten support.
148-CL I	Strengthening piece for batten support
1729-CL I	Upper cross-member (front or back)
1019-CL I	Right front post
1029-CL I	Left front post
1079-CL I	Right back post (w/o beam latch)
1089-CL I	Left back post (w/o beam latch)
1319-CL I	Right upper lateral crass-member
1329-CL I	Left upper lateral crass-member
1339-CL I	Right lower lateral. cross-member
1399-CL I	Left lower lateral cross-member
1619-CL I	Treadle set cross-member
1629-CL I	Middle lower cross-member
1639-CL I	Lower crossmember connecting back posts
1659-CL I	Middle cross-member connecting upright posts
1669-CL I	Breast or thread beam
164-CL I	Cloth beam w/ wheels & canvas apron
165-CL I	Warp beam with wheels
2012-CL I	Right batten sword + iron-fitt. (low. fix. beater)
2032-CL I	Left batten sword + iron-fiat. (low. fix. beater)
2092-CL I	Right batten sword (overhead beater)
2052-CL I	Left batten sward (overhead beater)
2069-CL I	Batten handtree
2079-CL I	Batten sley
2089-CL I	Shuttle. race
2762-CL I	Horizontal roller support CB.
177-CL I	Vertical roller support CB,
182-CL I	Adjustment peg for vertical taller support CB.
161-CL I	Upper roller (w/ sockets) CB.
2629-CL I	Lower roller (with plastic pulleys) CB.
163-CL I	Upper roller socket CB.
153-CL I	Jacks (pair, assembled) Jack-type
135-CL I	Jack spacer Jack-type
2549CL I	Jack spacer (short) jack-type
168-CL I	Harness upper part
169-Ch I	Harness lower part
140-CL I	Floating lam
2551-CL I	Right lam divider Jack-ty
2552-CL I	Left lam divider Jack-type
137-C1 I	Lam support CB.
2373-CL I	Treadle set support
2349-CL I	Treadle
135-CL I	Treadle space
0-2329-CL I	Treadle set board (4 harnesses)
1-2329-CL I	Treadle set board (8 harnesses)
2-2329-CL I	Treadle set board (12 harnesses)
1922-CL I	Stoppers for overhead beater (pair)
181-CL I	Stop peg for lower fixed beater
3529-CL I	Board to center ratchet pawls
3672-CL I	Takeup motion handle with ratchet pawl
126-CL I	Brake treadle
-	

37

COLONIAL I Jack 4, 8 or 12s Jack, 4s C.-B. 45" or 60" (cont.)

Spring clip for harness frame end Heddle support SF-CL I Spring hook for heddle support H23-CL I Hook for heddle support H23-CL I Hook for harness frame H24-CL I Treadle set axle rod (4 harnesses) H25-CL I Treadle set axle rod (8 harnesses) H25-CL I Treadle set axle rod (12 harnesses) H26-CL I Treadle set axle rod (12 harnesses) H27-CL I Treadle set axle rod (12 harnesses) H26-CL I Treadle set axle rod (12 harnesses) H27-CL I Support rod for treadle springs H25-CL I Support rod for treadle springs H27-CL I Strengthening piece for take-up motion handle H27-CL I Take-up motion handle support H28-CL I Beam latch H29-CL I Steel brake circle H29-CL I Strengthening piece for brake H27-9-CL I Strengthening piece for brake H27-9-CL I Brake lever H27-9-CL I Brake turnbuckle H28-CL I Rod connecting brake treadle to brake lever H28-CL I Rod connecting brake treadle to brake lever H28-CL I Treadle hooks (set of 6) H28-CL I Ratchet wheel for take-up motion handle H28-CL I Ratchet wheel for take-up motion handle H28-CL I Ratchet pawl for cloth beam (short)
Heddle support Spring hook for heddle support Hook for heddle support Hook for heddle support Hook for heddle support Hook for harness frame Headle set axle rod (4 harnesses) Headle set axle rod (8 harnesses) Headle set axle rod (12 harnesses) Headle set axle rod (12 harnesses) Headle set axle rod (12 harnesses) Headle spring (with snap bowie) Headle spring (with snap bowie) Headle spring set axle rod (12 harnesses) Headle set axle rod (12 harnesses) Headle set axle rod (13 harnesses) Headle set axle rod (4 harnesses) Headle set axle rod (4 harnesses) Headle set axle rod (8 harnesses) Headle support Headle set axle rod (4 harnesses) Headle set axle rod (12 harnesses) Headle set axle rod (12 harnesses) Headle set ax
040 01 1 0 1 11 1 1
205CL I Crossmember connecting stabilizing posts METAL
900-CL I Right stabilizing post Left stabilizing post
412-CL I Stabilizing board429-CL I Clamping member for stabilizing board
900 2800 205-

Hook to fold back of the loom

Tip-proof stabilizers (pair)

175-CL I

821-CL I