



COMPACT 24"

WOOD		
18-CP	Right upright post (with harness guide)	
17-CP Left upright post (with harness guide)		
1106-CP	Upper cross-member	
206-CP	Right front post	
207-CP	Left front post	
208-CP	Right back post	
209-CP	Left back post	
211-CP	Treadle set cross-member	
210-CP	Lower back cross-member	
204-CP	Breast beam	
205-CP	Thread beam	
26-CP	Right cloth beam support (with bumper)	
30-CP	Left cloth beam support (with bumper)	
24-CP	Cloth beam with ratchet wheel	
25-CP	Warp beam with brake drum	
212-CP	Batten sword	
2703-CP	Stop peg on batten sword	
202-CP	Batten handtree	
203-CP	Batten sley	
22-CP	Harness frame without heddle support	
1101-CP	Jack box board (front or back)	
19-CP Jacks assembled to lam (longer iron-fittings for har		
20-CP	Jacks assembled to lam (long iron-fitting for harness 3-4	
135-CP	Jack spacer	
2549-CP	Jack spacer (short)	
2702-CP	Treadle set support	
213-CP	Treadle	
135-CP	Treadle spacer	
214-CP	Brake treadle	
1405-CP	Beam stick (replacing the canvas apron)	
METAL		
422-CP	Heddle support	
1203-CP	Upper heddle support hook	
423-CP	Lower heddle support hook	
1102-CP	Jack axle rod	
215-CP	Treadle set axle rod	
2801-CP	Iron-fitting connecting posts to upright post	
1706-CP	Sliding plate receiving side handle	
3200-CP	Take-up motion handle	
2404-CP	Beam shaft	
2908-CP	Beam machine bolt for crank	
307-CP	front beam ratchet pawl	
406-CP	Strengthening piece for brake	
14-CP	Brake wire circle	
472-CP	Brake lever	
2806-CP	Brake spring	
CAST-IRON		
2502-CP	Brake drum	
2402-CP	Ratchet wheel	
3000-5892	Crank	
PLASTIC		
2803-CP	Side handle	
2804-CP	Post iron-Fitting spacer	
9259-CP	Beater bumper (upright post)	
3300-9239	Sub-harness bumper	

2000 01	
2804-CP	Post iron-Fitting spacer
9259-CP	Beater bumper (upright pos
3300-9239	Sub-harness bumper
1702-CPHarness	guide

CORDS 1022-2808

Brake cord