

Leclerc Looms

Since 1876



ARTISAT 36" JACK-TYPE 8 SHAFTS BACK HINGE

TREADLES

1009-3628

1573 Savoie
C. P. 4 Plessisville, Qc.
G6L 2Y6
TEL: 819-362-7207
FAX: 819-362-2045
www.leclerclooms.com
info@leclerclooms.com



On receiving the loom, unpack and lay out the loom components.
Do NOT discard any packing material until all parts are inventoried.

Check the parts received against the parts list on pages #2 to #6 of the assembly instructions. Report any discrepancies to Leclerc immediately.


To assemble this loom, a minimum of 2 people are needed but it is recommended you use 3.

Loom Prepared by: _____


Inspected by: _____

Date: _____

PARTS LIST



8 FLOATING LAMS



1 CASTLE TOP COVER



Note for Leclerc in French:
 1) Poser les 2 vis de la base de pattes arrière pour le crochet.
 Tête ronde no 12, 1" avec rondelle de nylon
 2) Poser la pièce filetée du contrôle de friction sur la patte arrière gauche.
 3) Faire les trous sur les sabots pour le séparateur de pédale + les trous pour pentures




1 LEFT-HAND SIDE
 with base packed separately

1 RIGHT-HAND SIDE
 with base and brake treadle packed separately



1 friction control system bolt



1 FRONT CROSS-MEMBER

1 MIDDLE LOWER CROSS-MEMBER


Note for Leclerc in French:
 4) Corde de frein coton 40"
 5) Surveiller l'amanchement avec les pattes avant.



1 TREADLE ROD 27 3/4" with one push nut



1 MORE PUSH NUT 7/16"



2 TREADLE set SUPPORTS




1 PK. 10 YDS FOR BEAM STICK
 1 PK 5 YDS FOR BEAMING AND LEASE
 STICKS




1 SHUTTLE




1 DOZ. BOBINES 4"




1 CLOTH BEAM WITH RATCHET
 WHEEL (wood = 38 1/8")




1 WARP BEAM WITH BRAKE DRUM
 (wood = 38 7/8")




1 TAKE-UP MOTION HANDLE




1 BATTEN HANDTREE



1 BATTEN SLEY WITH SHUTTLE RACE



2 BREAST BEAMS




(back part)

Note for Leclerc in French: La planche avant et arriere de la boite à marmouset doit avoir les vis pour cordes à bascule et ressort à pédale
2 X 10 vis #12 x 3/4"

1 JACK BOX

(DO NOT REMOVE THE TAPE UNTILL IT IS INSTALLED IN THE LOOM)



20 3/8"


31 1/4"

36 1/8"



10 treadles with rocker piece


1 stabilizing post cross member assembly with 2 stabilizing back posts




1 Treadle Separator 40" long



10 Treadle springs with Loop cords 9"



8 SHAFT (harness) FRAMES



1 REED



2 LEASE STICKS



1 BEAM STICK



3 WARP RODS



1000 HEDDLES



1 HEDDLE AND REED HOOK 8 5/8" long
6140-9000



1 Black Screwdriver

1 Red Screwdriver



1 Adjustment wrench




10 treadle hooks 10"














10 pegs to lock the treadle hooks




60 TREADLE CORDS 6 1/2"




1 CRANK FOR BACK BEAM



Instruction Video showing all stages of the installation.




Lay the left side on the floor with caution (you can put a piece of cardboard on the floor). Removed the packing material and using three #14 round head screw 2½", affix the base to the left upright and the back post to the base.



Lay the right side on the floor with caution (you can put a piece of cardboard on the floor). Removed the packing material and using three #14 round head screw 2½", affix the base (the brake treadle is already installed) to the right upright and the back post to the base.


ATTENTION: Application of soap to the screws will make their insertion easier.




Place right-hand side A straight up beside the wall.

Using a 2" (50-mm) round-headed screw no 14, affix lower middle cross-member B to the bottom of left-hand side A.

The lower middle cross-member has a hole at either end; the narrow sides B1 must be above and under the cross-member and the wide faces B2 must be on the sides.



Unfold the front section of left-hand side A. Using a 1/4" x 1 3/4" (6mm x 45mm) carriage bolt and a 1/4" (6mm) wing nut, affix metal hook C to left-hand side front post D.





Using a 1/4" x 1 3/4" (6mm x 45mm) carriage bolt and a 1/4" (6mm) wing nut, affix metal hook C' to right-hand side front post D'.

Place the take-up motion handle E, with a 9/16" steel washer, on the right-hand side end of cloth beam F.

Note: The ratchet gear is on the right-hand side beam end.
The ratchet pawl affixed to the take-up motion handle must be lifted up.


Insert the end of cloth beam F into the holes in upper front cross-members G and G'. The hole in lower middle cross-member B must be right beside the hole at the bottom of right-hand side A`

Using a 2" (50 mm) round-headed screw no. 14, affix right-hand side A` to lower middle cross-member B.




Using two 2" (50 mm) round-headed screws no. 14, affix one of the two breast beams to the top of the front posts B and B`

The rounded edge must be towards the outside of the loom.




Using $\frac{1}{4}$ " x $3\frac{1}{4}$ " (6mm x 80mm) carriage bolts, plus $\frac{1}{4}$ " (6mm) steel washer and square nuts, attach front cross-member A to front posts B and B'



ATTACHING THE STABILIZING ASSEMBLY TO THE LOOM


Install the rear Stabilizing assembly (A) to the Warp Beam Posts using 6 Round Head Screws #8 - 1"

Anchor the hook (B) to the stabilizing post of the loom using 2 carriage bolts $\frac{1}{4}$ " - $2\frac{1}{4}$ " and 2 wing nuts $\frac{1}{4}$ " (the wings nuts go on the outside of the loom)



TREADLE SEPARATOR

Affix the Treadle Separator Board on top of the back of the side base and secure using 2 #8, 1 1/4" Round Head Screws.




TREADLE SET ASSEMBLY


Treadle Block

Place one washer between the last treadle and the treadle blocks.

Assemble the treadle set (in or out of the loom) as shown in picture using:
 1 treadle rod 27 3/4"
 10 treadles
 9 wood spacers
 2 treadle blocks
 2 x 9/16" washers
 2 X push nuts 7/16"
 (one is already on the rod)

Affix treadle set to the treadle cross-member using:
 2 carriage bolts 1/4" x 3"
 2 washers 1/4" (under cross member)
 2 Wing nuts 1/4"





Slide jack box B along the middle posts A, from bottom to top, and affix it to blocks C using eight 1½” (40 mm) round-headed screws no. 12.



NOTE: The 10 screws go in the front bottom of the loom.
The eyescrews go in the back bottom of the loom.

Install the heddles in the shaft frames. (see “WARP AND WEAVE” on page 10)

Remove the saran wrap on the jack box.

Slide shaft frames T between dividers Q.
The shaft frames must rest on the plastic supports U of the jacks


NOTE: Some shafts may be tight between the castle frame until the castle top is attached.




Join the "S" hook of the jacks D to the eyelet of the FLOATING lam E.

Castle cover

Complete the assembly by securing the Castle cover with 4 #12 1½" flat screws.
Make sure to screw into the pre-drilled holes of the castle.



Wing nut 5/16" (8 mm)




Carriage bolt
5/16" X 2 1/2" (8 mm X 65 mm)

Install the treadle cords with the treadle hooks.


Using the carriage bolts, steel washers and square nuts, attach the batten sley A (with shuttle race) to the batten swords B.

Then affix the batten handtree C to the batten swords B.




Install reed D in the slots of batten handtree C and batten sley A.

Adjust batten handtree C by sliding the bolts in the slots of the batten swords to firmly hold the reed.



You can install now or just before weaving the treadles springs. After the installation, the treadles will be all at the same height.






Unhook brake treadle cord C from the brake release treadle.



Hold circular wire brake shoe D up slightly to the rear of the loom.


Insert one end of the warp beam (which has only a metal post) into the left-hand side back post.




Insert the friction brake drum of the warp beam into the circular wire brake shoe D.

Do not unroll the brake shoe (brake circle), just slide the warp beam into it





Using two 2" round-headed screws no 14, affix the breast back beam to the back posts.



Join the front "S" hook of the brake lever to the brake loop cord so the tension on the spring will be high enough to lock the warp beam while weaving.


The warp beam should turn with some friction clockwise (while standing at the right side of the loom near the brake system) and this is the warping rotation. However, you should always release the tension on the friction brake system by disconnecting the spring from the loop cord (S hook) when you are warping the loom.

To advance the fabric when weaving, depress the brake treadle just enough to release the warp beam. Depressing the brake treadle too far may cause the brake cable to come off the brake drum.

Join the brake treadle to the S Hook in the back of the Brake Lever. Adjust the length so the brake treadle is at the comfortable height. Make a double knot at the brake treadle eye.

FIRST TREADLE TIE-UP

Select any treadle and tie the Lams to the Treadles using the 7½" cords supplied with the loom. Use the threading hook to help pass the cord through each hole of the lam.



TREADLE HOOK AND ROCKER LOOP CORD


Slide the Treadle Hook through the Screw Eyes and the treadle Cord Loops. Before the last Screw Eye, insert the Hook through the Treadle Spring loop cord and secure with the peg in the front.

In the Treadle rest position (up) there should be no or very little tension on the Spring.

However, slack on the spring cords is not desirable.

When all treadles are tied up, they should be at almost the same height. The top front part of each treadle should be app. at 8¾" to the floor.


Install the Treadle Rocker Loop Cord on the Jack box screw at the black mark as a starting point.



FIRST SHED

When you depress the treadle, the rocker loop cord raises the front of the rocker setting the shafts at the correct Level.

See next page for more info on adjusting the length of each rocker loop cord.



VIEW FROM THE BACK OF THE LOOM SHOWING THE TREADLE AT REST POSITION AND DEPRESSED.



ADJUSTING THE SHED (Length of the Rocker Loop cord)

The key to a wide clean shed is the proper adjustment of the Rocker Loop Cord. Once you have completed the hookup of the Cords and Springs, start at one end of the Treadle Set and depress each Treadle one at a time noting the position of the bottom Shed. Adjust each Shed by shortening or lengthening the Loop Cord. When properly adjusted, the bottom Shed of each Treadle should just kiss the Race Plate and the top Shed should be uniform across the width of the Loom. (see diagrams for examples)

Picture #32 shows an uneven Shed caused by Rocker Loop Cords being out of adjustment.


Picture #33 shows properly adjusted Rocker Loop Cords with the bottom Shed just kissing the Race Plate and the Top Shed uniformly even across the width.

It is very important to maintain a reasonable amount of tension on the Warp when making adjustments and while weaving in order to keep a wide, clean Shed.


The design of the system provides a greater lifting force on the Shafts with considerably less leg pressure required to depress the Treadles. With a few Picks on each new project, the Weaver will find the correct Warp tension required to produce the desired PPI (Picks per Inch) in the Cloth, while maintaining a wide, clean Shed.




BEAMING



Thread the 10 yard (9 m) cord through the middle hole of beam stick A. Then pass the two ends (equal in length) of this cord through the middle holes of the warp beam.




Continue threading the cord through the warp beam and beam stick A. Knot the cord at each end of the beam stick. Adjust the cord so it is equally divided and keeps the beam stick straight. This will reduce warp wastage.



**Warp beam
advance
control
system**


This system will eliminate excessive warp yarn advance when releasing the brake system at cloth take-up. This friction system is adjustable and have to be released when winding the warp on.

Just screw the wing nut with nylon bolt to the left back post. Screw in to increase the friction or unscrew it to release.



Screw eyes have been affixed to the inner side of the main post.
After having passed a string through the holes of the lease sticks, tie the ends of this string to the thread beam and to the screw eye. Do the same operation with the other end of the lease sticks.

The lease sticks will then be held at a practical height for threading



**We at Leclerc encourage Weaver feedback
on this and all our products. Please
send your comments to Leclerc Loom Co.
info@leclerclooms.com**

HAPPY WEAVING